



AERIAL WORK PLATFORM SAFETY

You are responsible for the safe operation of this equipment. The operator must carefully read and understand any warnings, safety signs, and instructions provided with or located on the equipment.

DO NOT OPERATE IF YOU SUSPECT A MALFUNCTION OR IF YOU ARE NOT AUTHORIZED OR TRAINED TO RUN THE AERIAL PLATFORM!!!

- 1) Ensure that the lift is on a firm and level surface. The aerial platform shall not be operated in many manner on grades, side slops or ramps exceeding those for which it is rated by the manufacturer.
- 2) **ELECTROCUTION HAZARD!** Inspect work area for obstacle and maintain adequate clearance from overhead obstructions and energized electrical conductors and parts.
- 3) Cease operation and call for further instructions if you suspect a lift malfunction. Never operate a damaged machine!
- 4) Guardrails are to be installed and positioned, and access gates or openings shall be closed.
- 5) Personnel shall maintain firm footing on the platform floor. Climbing on the guard rails is prohibited. The use of planks, ladders, or any other devices for achieving additional height or reach is prohibited.
- 6) The operator shall ensure all occupants of the platform wear personal protective equipment as required.
- 7) Know the rated capacity of the aerial lift and DO NOT use as a crane!
- 8) Do not operate the lift during extreme wind conditions or exceed manufacturers horizontal force. If unsure, call for further information.
- 9) Care shall be taken to prevent rope, electric cords, and hoses, etc., from becoming entangled in the aerial platform.
- 10) Stunt driving and horseplay are prohibited!

**Personnel shall have read and be familiar with the operators manual and shall abide by the safety rules and practices. If there is any doubt as to the safe operation or safety of the equipment, DO NOT USE!
CALL US IMMEDIATELY!!!**