



### AIR COMPRESSOR SAFETY

**Air is dangerous! DO NOT point compressed air lines at people for any reason! Serious injury or death might occur!**

- 1) Unit will get HOT during operation. Never touch the discharge tubing, engine, motor or compressor pump.
- 2) Gas engines should only be operated in well-ventilated, outdoor areas.
- 3) Air compressor should never be used to supply breathing-quality air.
- 4) Keep safety valve clean. Never remove and replace with a plug.
- 5) Make sure to drain tank regularly.
- 6) Always use safety glasses when using compressed air.
- 7) The compressor operated automatically while the power is connected and turned on, or the engine is running.
- 8) If towing air compressor, attach and check safety chain. Chains should be crossed. Chain should not drag on ground, but should allow vehicle to turn without pulling chain tight.

**It is not possible to warn about all hazards associated with operating this equipment. You must use your own good judgment. If you are in doubt as to the safe operation of this equipment, STOP WHAT YOU ARE DOING!  
CALL US IMMEDIATELY!!!**