



PAINT SPRAYER SAFETY

**SOLVENT AND PAINT FUMES CAN IGNITE. SEVERE INJURY AND/OR PROPERTY DAMAGE CAN OCCUR. NEVER AIM THE GUN AT ANY PART OF YOUR BODY OR ANYONE ELSE. A HIGH PRESSURE STEAM PRODUCED BY THIS EQUIPMENT CAN PIERCE THE SKIN, LEADING TO SERIOUS INJURY. IF YOU ARE UNSURE AS TO THE SAFE OPERATION OF THE UNIT, STOP WHAT YOU ARE DOING!!!
CONTACT US IMMEDIATELY!!!**

- 1) Never allow any part of the body to touch the fluid stream or touch a leak in the fluid hose.
- 2) Always shut the sprayer off and release all pressure before servicing, cleaning the tip or guard, changing tip, or leaving unattended. Pressure will not be released by turning off motor. The PRIME/SPRAY valve must be turned to PRIME to relieve the pressure.
- 3) Inspect the hose before each use. A leak can inject material into the skin.
- 4) Never use a spray gun without a trigger lock and trigger guard in place and in good working order.
- 5) Provide extensive exhaust and fresh air to keep the air within the spray area free from accumulating flammable vapours.
- 6) Do not smoke in spray area. Avoid all ignition sources.
- 7) The equipment and objects in and around the spray area must be properly grounded to prevent static sparks.
- 8) Plastic can cause static sparks. Never hand plastic to enclose a spray areas. Do not use plastic drop cloths when spraying flammable material.
- 9) The paint sprayer contains arcing parts that emit spark and can ignite vapours. Keep sprayer at least 20 feet from the spray object in a well ventilated area preferably in a separate room.

**If you do not understand the safe operation of the machine, or believe it to be not operating properly,
CALL US IMMEDIATELY!!!**