



CONCRETE AIR TOOL SAFETY

STAY ALERT, WATCH WHAT YOU ARE DOING AND USE COMMON SENSE WHEN OPERATING AN AIR TOOL. IF YOU DO NOT UNDERSTAND THE SAFE OPERATION OF THE EQUIPMENT, STOP WHAT YOU ARE DOING!!! CALL US IMMEDIATELY!!!

- 1) Inspect all air tools. Make sure all components are tight and that no parts are missing or damaged.
- 2) Check air pressure to ensure proper working pressure of the tool.
- 3) Do not use the tool for anything other than the intended purpose.
- 4) To avoid tool damage, do not hammer on the way out when using a chipping gun or larger breaker.
- 5) Do not turn the tool toward your body or anyone else.
- 6) Do not adjust, remove or store tools without disconnecting the air supply and relieving the air pressure in the hose.
- 7) Do not change the tool steel or any accessories without disconnecting the air supply.
- 8) Do not leave the tool idle while connected.
- 9) Do not operate an air tool with damaged tool steel.
- 10) Wear proper work gloves, safety glasses, and hearing protection when operating the tool.

Only use this tool in the applications for which it was designed. Follow the instructions on the proper use of the air tool. If you do not understand the safe operation of this equipment, CALL US IMMEDIATELY!